Elevate™ Adjustable Containment End of Row Panel



WARNING: Improper use of this product may lead to serious injury or death. Read and understand all instructions for proper installation and use of this product.



WARNING: The adjustable containment panels must be secured to adjacent panels with provided corner brackets.



WARNING: The end of row adjustable containment panel must be securely fastened to end of row door.




WARNING:Installation of aisle Containment products may require the use of ladder, Scaffolds, and other climbing tools. Follow all climbing device procedures and observe all safety and warning precautions.

Intended Use

Install this assembly only in a restricted service environment, such as a data center. Use indoors only, in environmentally controlled areas; do not use outdoors, in harsh environments or in air-handling spaces or in direct proximity to unshielded high voltage.


The 14625-XXX Adjustable End of Row Ailse Containment Panels are intended to be used to form a barrier region above a 32770-XXX or 32780-XXX Aisle Containment Door.

This instruction is to be used as a general guideline as the actual field installation will depend on system containment requirements.



- 8mm Socket wrench
- 10mm Socket wrench
- 13mm Socket wrench
- Utility knife

Included Hardware:






M8x12 Serrated Flange Screw, Qty (14)



M6 Serrated Flange Nut, Qty (8)



M5x8 Flange Screw, Qty (8)



Upper Corner Bracket Qty (2)



Mid Seals, Qty (2)



Edge Seals (2 Horizontal, 2 Vertical)



Lower Mid Panel Seal, Qty (1)



IIS-714625-001, 01/03/24, Rev. 1, CPI/REL 800-834-4969 (USA & Canada) • www.chatsworth.com • techsupport@chatsworth.com For international phone numbers, see our website or contact CPI Tech Support.

This drawing contains proprietary and confidential information and is protected by U.S. and international law. Unauthorized reproduction, disclosure or use of the drawing or the information therein is expressly forbidden except as agreed to in writing by Chatsworth Products, Inc.


Elevate™ Adjustable Containment End of Row Panel


Installation Instructions:

 Attach (2) Upper Corner Brackets with (3) M8X12 each as shown in Figure2. Measure the inside opening dimension between the Upper Corner bracket flanges (Dim A) as shown in Figure 2.

Maximum and minimum "Dim A" values for the available end of row panel assemblies are given in Table 1.

TABLE 1.





Page 2 of 8


Elevate™ Adjustable Containment End of Row Panel

2. Measure the distance between the lower edge of the Upper Corner Bracket installed in Step 1 to the top of the edge of cabinet panel base as shown in Figure 3. Trim flexible seal strips to fit and install with the curve

directed inwards as

shown.


Installation Instructions:



Elevate™ Adjustable Containment End of Row Panel

Installation Instructions:


3. Install the cut with the curve directed inwards as shown. Slit the seal with a knife just above the door header as shown. Repeat for both sides of the door.




Elevate™ Adjustable Containment End of Row Panel

Installation Instructions (Con't):


- 4. Lift the right side End of Row Containment Panel onto the End of Row Door header. Align Qty (4) M6 studs with the slots on the bottom of the panel frame as shown in Figure 5.
- 5. Attach the lower frame using M6 Serrated nuts as shown.



Elevate™ Adjustable Containment End of Row Panel



Elevate™ Adjustable Containment End of Row Panel



Page 7 of 8

Elevate™ Adjustable Containment End of Row Panel

